

# The Forgotten Five

Operators, five grease fittings on the small emplacement excavator get overlooked because they're out of sight in back of the vehicle.

## Backhoe Pedal Fittings

Without lube, the backhoe's swing-foot pedals can seize up. Then you can't move the backhoe left or right during construction operations.

So keep the left and right pedals lubed with 4 to 5 pumps of grease at scheduled services.



THIS  
PEDAL  
IS **HARD**  
TO PUSH  
**DOWN!**



## Pintle

If you don't lube the pintle's fitting like LO 5-2420-224-12 says, rust freezes the pintle into position. Then it won't turn. If that happens, a towed trailer can tip over.